

# ASSEMBLY INSTRUCTIONS



MODEL 90154420T Gameday Shelter 90" x 60"

## SAFETY WARNING - DOs AND DO NOTs

EVERYONE WHO USES THIS CANOPY SHOULD READ THIS MANUAL AND BECOME FAMILIAR WITH ALL SAFETY WARNINGS AND PRECAUTIONS FOR SAFE USE, ASSEMBLY, CARE, MAINTENANCE, AND STORAGE. KEEP THIS MANUAL SO YOU CAN REFER TO IT LATER.

**⚠ WARNING** FLAMMABILITY WARNING KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS CANOPY FABRIC  
This canopy is made with flame resistant fabric which meets CPAI-84 specification. IT IS NOT FIREPROOF. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the canopy fabric may render the flame-resistant properties ineffective. Your failure to follow this warning could cause death, serious injury, or permanent disability to you or others.

**For these reasons :**

- DO NOT use matches, lighters, stoves, heaters, grills, lanterns, candles, cooking equipment, or other fuel-burning devices inside or near a canopy.
- DO NOT build fires inside or near a canopy.
- DO NOT leave campfires unattended.  
Your failure to follow this warning will cause death, serious injury, or permanent disability to you or others.

**PROTECT YOUR CHILDREN**

Children will not understand and appreciate safety warnings and will not know how to avoid or respond to these hazards if no adults are present.

**For these reasons :**

- DO NOT leave children unattended inside a canopy or in camp .
- DO NOT allow children to assemble a canopy.
- DO NOT allow children to enter or exit a canopy except through the door.

Your failure to follow this warning will cause death, serious injury, or permanent disability to your children.

## CARE

DO NOT LEAVE YOUR CANOPY SET UP IN DIRECT SUNLIGHT LONGER THAN NECESSARY. THE SUN’S ULTRAVIOLET (UV) LIGHT DEGRADES ALMOST EVERY FABRIC AND MATERIAL. IF LEFT IN SUNLIGHT FOR PROLONGED PERIODS OF TIME, FABRIC WILL FADE AND WEAKEN. DO NOT STORE THE CANOPY ON CONCRETE FLOOR. DO NOT SPRAY THE CANOPY WITH INSECTICIDE.


Although our tents and canopies are constructed to rigid specifications, periods of wind or rain soaking the ground may loosen the stakes and cause the uprights to sink into the ground. This will weaken the rigidity of the overall structure. Water pockets may also form in the roof if the unit is not assembled taut, possibly causing broken frames and torn fabric.

## REPLACEMENT PARTS

If you have questions or need to order a part, call 1-800-635-0461 or send an e-mail to [warranty@sierradesigns.com](mailto:warranty@sierradesigns.com)  
Have your model number or part number ready when you call. DO NOT ORDER BY REFERENCE KEY NUMBER.

Send your request for parts to:  
**Sierra Designs**  
1 International Ct.  
Broomfield, CO 80021

KEY NO.	MODEL NO 90154420T Gameday Shelter 90" x 60"		QTY REQ
	DESCRIPTION	PART NO.	
A	Main Pole		2
	Complete Frame set		1
	Sand Bags		4
	Steel Stake	PINSTAKE	4



# ASSEMBLY INSTRUCTIONS




MODEL 90154420T Gameday Shelter 90" x 60"

**IMPORTANT:** WE ADVISE YOU TO ASSEMBLE THE STRUCTURE ONCE BEFORE GOING OUT TO BECOME FAMILIAR WITH THE ASSEMBLY OF THE TENT.


**NOTE:** PLEASE LOOK AT THE REPLACEMENT PARTS DIAGRAM TO SEE HOW YOUR FRAME IS ASSEMBLED.

RECCOMENDED FOR AT LEASET 2 PEOPLE TO SET UP


**STEP 1:** Spread canopy out flat with pole sleeves up.




**STEP 2:** Stake the canopy to the ground by inserting stakes though the webbing loops at the side corners of the structure. Hammer the stakes into the ground at a 45° angle, making sure the sides are pulled out evenly.




**STEP 3:** Extend the poles by pulling out each section and placing the ends into the metal ferrule connectors. You will have 2 poles.




**STEP 4:** Slide each fiberglass pole (A) through the sleeves on the top of the canopy roof. diagonally across tent body, making sure the poles pass thru sleeves. Position poles so that equal pole lengths extend on either side of the pole sleeves.




**STEP 5:** Starting at one side of the canopy, place the ends of the fiberglass frame pole into the fast feet located at the base of the canopy. Walk to the other side. Push upward on the pole to create an arch. Place pole ends into remaining fast feet.




**STEP 6:** Clip the plastic hooks to the fiberglass frame poles.



**STEP 7:** There is a large black hook that goes over both poles where the poles cross at the sides of the canopy to hold them together.



Canopy should appear as shown.



**NOTE:** Sandbags are provided for use at the beach. Fill the bags with sand to hold the canopy in place.

**NOTE:** To take down canopy, follow steps above in the reverse order. Place stakes into stake bag and poles into pole bag, which are provided. The canopy should be folded into equal parts toward the center to distribute the bulk. Place pole bag on canopy and start a small tight roll, the width of your carry bag. Once rolled, secure with strings or rope and place into carry bag.

**MAKE SURE CANOPY IS CLEAN AND DRY BEFORE STORING.**