



# Clip Flashlight 2

## PITCHING INSTRUCTIONS


Congratulations on the purchase of your new Sierra Designs tent! In order to familiarize yourself with your new tent, we recommend you "test pitch" it before embarking on your wilderness adventure.

PACKAGE INCLUDES: Tent Body, Rain Fly, 2 Poles, 4 Guy Cords, 9 Hex Peg Stakes, 1 Pole bag with attached stake bag.

**STEP 1:** Find an even piece of ground; be sure the area is clear of debris. Lay out your tent as shown. Stake the 4 corners (circled).



**STEP 2:** Assemble poles. Insert long pole into SD Anchor at front of tent and short pole into SD Anchor at rear of tent.



**STEP 3:** Connect Tent Lite Hook to poles.



Tent Lite Hook



**STEP 4:** Lay the rain fly over the tent body matching RED corner of the tent with the RED corner of the fly.



Match RED corner of fly with RED corner of tent body




**STEP 5:** Connect the velcro loops on the underside of the fly to the rear and front hoop poles. (6 total)




Velcro Loop



**STEP 6:** Attach fly cord loop around 4 pole tips. Adjust tension by pulling down on String Lock cord. Clip SR buckles at rear of tent and adjust tension.



SR Buckles



Attach fly cord loop around pole tip

# Clip Flashlight 2

## USING YOUR TENT



**GUYING OUT YOUR TENT:** Your tent includes guy out loops, guylines, and stakes. It is good practice to always guy out your tent, but is absolutely necessary when it's windy.



Use the black LINE-LOK to adjust the length of the guy line.



Guy out your tent where shown below to prevent pole rotation/breakage during high winds.



Stake out the end of the guy line into the ground.

**OPEN AWNING SETUP:** The vestibule panel on your tent can be configured to provide awning coverage in front of the door.

1. Tie guylines to yellow webbing loops on vestibule panel corners.
2. Insert trekking pole tips through yellow webbing loops.
3. Stake out guylines



**STRING LOCKS:** The corner points of your tent feature String Locks providing a range of stake out options. Lift up on the tab to decrease tension. Pull on the knotted end to increase tension.

